


|                                                  |  |                                                                                         |                                                                                                   |
|--------------------------------------------------|--|-----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| <b>Anziehvorschrift für Zylinderkopf</b>         |  | <b>162.483</b><br>passend für / suitable for<br>adaptable à / adaptable a<br><b>PSA</b> | <br>Das Original |
| <b>Tightening Instructions for Cylinder Head</b> |  |                                                                                         |                                                                                                   |
| <b>Instructions de serrage pour culasse</b>      |  |                                                                                         |                                                                                                   |
| <b>Prescripciones de apriete para culatas</b>    |  |                                                                                         |                                                                                                   |

Schraubenkopf / Head shape  
 Tête de vis / Cabeza de tornillo



758.400  
M 11 x 184,5

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



Anziehen/ Tightening/ Serrage/ Apriete
 

\* 40 Nm  
 ➤ 260°

Zeichenerklärung / Explanations / Explication / Explicacion
 

|   |                                             |                              |                                |                                       |
|---|---------------------------------------------|------------------------------|--------------------------------|---------------------------------------|
| * | neue Zylinderkopf-schrauben verwenden       | use new cylinder head bolts  | utiliser des vis neuves        | emplar tornillos nuevos               |
| ★ | Warmlauf (80°C)                             | warm up time (80°C)          | chauffage (80°C)               | calentamiento (80°C)                  |
| □ | Schrauben einzeln lösen und wieder anziehen | loosen and tighten each bolt | deserrer et serrer vis par vis | aflojar y apretar tornillo a tornillo |
| ● | Setzzeit                                    | relaxation time              | durée de tassement             | tiempo de espera                      |
| ➤ | Drehwinkel                                  | torque angle                 | angle de serrage               | ángulo de giro                        |

**Motortyp / Engine type / Type de moteur / Tipo de motor**  
  
 1,70 mm ÷  
  
 Mot. TUD 5, 1527 ccm, 43 kW (58 PS)  
  
 AX 15 Diesel                      7/1994>

ElringKlinger AG, Max-Eyth-Str.2  
 72581 Dettingen / Erms. Tel. 07123/724 601

**\*162.483\***