



Anziehvorschrift für Zylinderkopf		442.822	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a PSA	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
267.550 M 12x1,5x126			
Anziehen/ Tightening/ Serrage/ Apriete	* 20 Nm 60 Nm ➤ 110° ➤ 110°		
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø: 85,8 mm; 𐀀: 1,35 mm			
Mot: DW10CTED4 2,0 ltr. 16V 120 kW (163 PS)			
407, 508, 5008, 308 ab 06/2009➔			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*442.822*	