



Anziehvorschrift für Zylinderkopf		075.920	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a BMW	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
802.661 M 12x1,5x147			
Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ➤ ➤	40 Nm 80 Nm 50 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Wärmelauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 1,45 mm, Ø 84,5 mm, 1 Loch/hole/trou/agujero/foro			
Mot.: M47 D20			
E46 318d, 320d E39 520d			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*075.920*	