


Anziehvorschrift für Zylinderkopf		130.682		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a Citroën, Peugeot		
 152.550 M 12x1,5x123		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete 		
Anziehen/ * 20 Nm Tightening/ 60 Nm Serrage/ ➤ 90° Apriete ➤ 90°				
Zeichenerklärung / Explanations / Explication / Explicacion				
* ➤	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 84 mm ✚: 1,42 mm 5 Löcher/holes Mot: DW8, DW8B, 1WZ, WYJ, WYZ 1,9 Ltr. Diesel 44 - 51 KW Berlingo, C15, Jumpy, Xsara, Scudo, 206, 3, 306 Expert, Partner, Corolla				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*130.682*		