

Anziehvorschrift für Zylinderkopf		135.072		
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a PSA, Fiat, Ford, Volvo		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		



267.550
M 12x1,5x126

Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ➤ ➤	PSA DW10ATED4: 20 Nm 60 Nm 60 Nm 110° 110°	* ☐ ➤ ➤	PSA DW12TED4 20 Nm 60 Nm 20 Nm 60 Nm 110° 110°	* ➤	Fiat, Ford, Volvo: 30 Nm 60 Nm 220°
---	---	---	---	--	------------	--

Zeichenerklärung / Explanations / Explication / Explicacion

✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

✚ 1,4 mm, Ø 86 mm, 4 Löcher/holes/trous/agujeros

Mot.: G6DA, G6DB, G6DC, G6DD, G6DE, G6DF, AZWA
QXWA, QXWB, DW10ATED4, DW10BTED4, DW12TED4
RHR, RHK/DW10UTED4, D4202T/T2

Focus, C-Max / 307, 406, 407, 607, 807
V40II, V50 / C4, C5, C8

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*135.072*
--	------------------