



Anziehvorschrift für Zylinderkopf		240.160 passend für / suitable for adaptable à / adaptable a Audi / Bentley	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 233.930 M 10x1,5x134				
Anziehen/ Tightening/ Serrage/ Apriete	* M10 30 Nm 60 Nm ➤ 90° ➤ 90°	M6 10 Nm ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor V8, TFSI, rechts/right Mot. CEUC, CEUA, CGTA, CTFA, CRDB CMMC, CMMD, CYCA, CYCB S6, RS6, S7, RS7, A8, S8 New Continetal, Flying Spur				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*240.160*	