



Anziehvorschrift für Zylinderkopf		240.170	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for	
Instructions de serrage pour culasse		adaptable à / adaptable a	
Prescripciones de apriete para culatas		Audi / Bentley	
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
233.930 M 10x1,5x134			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	M10 30 Nm 60 Nm 90° 90°	M6 10 Nm 90°
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf-schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage
	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro		
Motortyp / Engine type / Type de moteur / Tipo de motor V8, TFSI, links/left Mot. CEUC, CEUA, CGTA, CTFA, CRDB CMMC, CMMD, CYCA, CYCB S6, RS6, S7, RS7, A8, S8 New Continetal, Flying Spur			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*240.170*	