



Anziehvorschrift für Zylinderkopf		245.980	
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a Suzuki Das Original	
 178.520 M 10x80x1,25 I6K SW8		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete 	
Anziehen/ Tightening/ Serrage/ Apriete		* 30 Nm 48 Nm □ 0 Nm 30 Nm 48 Nm 60 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor 1,1 Ltr. 16V Mot.: F10D / F10DN (46kW/63PS) Suzuki Alto			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*245.980*	