

Anziehvorschrift für Zylinderkopf		650.420 passend für / suitable for adaptable à / adaptable a FORD	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			

Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo	Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
--	---



⑥	②	④	⑧
⑤	③	①	⑦

642.570
 M10x105x1,5

Anziehen/ Tightening/ Serrage/ Apriete	* 10 Nm 40 Nm □ - 45° 30 Nm ➤ 90° ➤ 90°
---	--

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 73mm ⚙: 0,70mm

Mot:

M1CB, M1CA, M1DA, M1JA, M1JC, M1JE, M2DA
 SFDA, M2GA, M2GB, P4JC, P4JD, P4JA, P4JB
 SFCD, SFCC, SFCA, SFCB, SFJA, SFJB, SFJD
 SFJC, XMJA, XMJB
 1.0ltr. Ecoboost / Duratec

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*650.420*
--	---------------------------------------