



Anziehvorschrift für Zylinderkopf Tightening Instructions for Cylinder Head Instructions de serrage pour culasse Prescripciones de apriete para culatas		729.041 passend für / suitable for adaptable à / adaptable a PSA/BMW	 Das Original
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo			
		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
 426.830 M8x1,25x35			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	Pos. 1-10: 30 Nm 90° 90° Pos. 11-12: 15 Nm 90° 90° Pos. 13: 25 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) desserrer et serrer vis par vis durée de tassement angle de serrage
	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro		
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 78 mm; $\frac{1}{4}$: 0,94 mm Citroen, Peugeot, Opel, BMW, Mini			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*729.041*	