

Anziehvorschrift für Zylinderkopf		809.750			
Tightening Instructions for Cylinder Head					
Instructions de serrage pour culasse					
Prescripciones de apriete para culatas					
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a		Opel	Das Original
					
803.050 M 12x1,5x102		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete			
		106237 95148			
Anziehen/ Tightening/ Serrage/ Apriete	Y17DT/Y17DTL * 20 Nm ➤ 40 Nm ➤ 60° ➤ 13° ➤ 60° ➤ 13°	Z17DTH/Z17DTL * 15 Nm ➤ 39 Nm ➤ 60° ➤ 60°			
Zeichenerklärung / Explanations / Explication / Explicacion					
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos	
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)	
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo	
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera	
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro	
Motortyp / Engine type / Type de moteur / Tipo de motor					
Mot. Y17DT, Y17DTL, Z17DTL, Z17DTH					
Corsa C, Astra G, Astra H, Meriva					
✚ 1,40 mm (2 Loch/hole)					
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*809.750*		