


Anziehvorschrift für Zylinderkopf		272.620 passend für / suitable for adaptable à / adaptable a Nissan/Renault	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
Anziehen/ Tightening/ Serrage/ Apriete	* ☐ ☐ ➤	40 - 49 Nm 98 - 102 Nm 40 - 44 Nm 90° - 95° 90° - 95°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Dicke/Thickness 0,70 mm 2 Kerben/notches			
Mot. ZD30DDTi/ZD3/DXi 3,0 Ltr. 2953ccm Diesel 113/116 kW (154/158 PS) Patrol GRII Y61, Terrano II R20 Master III 2000 →			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*272.620*	